GreenSeeker

HANDHELD CROP SENSOR

The Trimble® GreenSeeker handheld crop sensor is an affordable, easy-to-use measurement device used to assess the health—or vigor—of a crop in order to make informed nutrient management decisions on your farm.

Use the GreenSeeker handheld to instantly take a reading of your crop's health. Simply aim the sensor on the underside of the device at a crop 24 to 48 inches (60 - 120 cm) away and pull the trigger to get a reading.

Power	
Battery	3.7V DC nominal, 1130 mAh
Charging	5V DC, 320 mA max
Charge Time	5.5 hours (full charge)
Continuous Operation Time	12 hours

Mechanical	
Dimensions	3.5" x 10.5" (9 cm x 27 cm)
Weight	11 oz. (310 g), including battery

Housing	
Material	Xenoy plastic
Rating	IP54
Optical	

Optical	
RED	660 nm
NIR	780 nm
Field of View	10" at 24", 20" at 48"
Operating Height	24" – 48"

Readings can be used to make non-subjective decisions regarding the amount of fertilizer to be applied to your crop, resulting in more efficient use of fertilizer—benefiting your bottom line as well as the environment.

Collecting data is easier than ever with Bluetooth® connectivity built into the sensor. With a linked mobile device running a compatible app (such as GreenSeeker BT Logger for Android™mobile devices), NDVI values can be recorded for future analysis.

Connectors	
Remote Trigger Switch Port	2.5 mm Stereo phone jack
Charging Port	Micro-B (micro USB)

Operational Range	
Charging	50 °F - 104 °F
Temperature	(10 °C - 40 °C)
Operating	50 °F - 122 °F
Temperature	(10 °C - 50 °C)
Storage	14 °F - 158 °F
Temperature	(-10 °C - +70 °C)

Connectivity	
Bluetooth	Bluetooth Low Energy (BLE) 5.1

Key Benefits

- Easy to use—simply pull the trigger to get a reading
- Make objective farm decisions NDVI values have been used for decades to determine specific fertilizer rates
- Save money and the environment by applying fertilizer only where needed
- Connect wirelessly to your mobile device via Bluetooth for rapid data collection with no extra equipment



Recommended GreenSeeker Android app



Recommended GreenSeeker iOS app



Contact your Trimble Ag Reseller today

TRIMBLE AGRICULTURE DIVISION

Trimble Agriculture Division 10368 Westmoor Drive Westminster, CO 80021

- +1-720-887-6100 Phone
- +1-720-887-6101 Fax

TRIMBLE INC.

Corporate Headquarters 935 Stewart Drive Sunnyvale, CA 94085 USA

- +1-408-481-8000 Phone
- +1-408-481-7740 Fax

© 2012-2022, Trimble Inc. All rights reserved. Trimble and the Globe & Triangle logo are trademarks of Trimble Inc., registered in the United States and in other countries. The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Trimble Inc. is under license. All other trademarks are the property of their respective owners. PN 022503-1487B-en-US (02/22)

